

Samsung is one of the world's largest companies in the world. They are headquartered in Samsung Town in Seoul, South Korea. Samsung was founded as a trading company but entered the electronics market in the 1970s. Notable businesses Samsung operates include a theme park in South Korea, named "Everland".

In 2015, Samsung announced they wanted to be world's biggest appliance Maker. This is not an easy task, they need to compete heavily with other well-known multinationals, such as Whirlpool, General Electric, Bosch, Electrolux and Kenmore. Samsung hopes the win the battle by introducing Smart Home designs. The Chef Collection of refrigerators, will have sparkling, purified water while different compartments can be cooled to different temperatures; something unseen ever before.

In consumer reports' test, a whirlpool fridge will give you other options than an LG fridge. If you are aiming for a stainless steel front with french doors; most manufacturers offer those options nowadays. Samsung Appliances, GE, Bosch and Electrolux are offering a variety of ice makers with filtered water. Newer varieties even offer sparkling water. If you drink a lot of water and are looking for unlimited filtered, fresh water straight from your fridge, then make sure to buy a fridge with a water filter.

If you are the proud owner of a fridge with a water dispenser, you came to the right place. In this article we will tell you all about how to replace Samsung fridge filters, how to light reset the water filter and how to change a samsung water filter.

In this article we will see how to replace a samsung fridge filter, how to reset the Samsung water filter and how to change a da29-00003g samsung filter and how to replace a da29-00003f water filter.

1. Replace rsg5ucrs samsung fridge filters. Avoid contamination, replace the filter maximum every 6 months.

Changing the filter of the Samsung rsg5ucrs American-style fridge-freezer is probably easier than you think. 90% of these fridges has an internal water filter. When the filter indicator light changes to red, it is time to change the filter. Typically this happens about every 6 months.

The following instructions are for internal filters only (~90% of Samsung rsg5ucrs fridge-freezers carries an internal filter).

- To remove the water filter, twist the filter to the left or counterclockwise to unlock
- Gently pull it out and discard (the water will shut off automatically)
- Gently push in the new water filter and turn it to the right
- If the padlock symbol matches up with the symbol on the filter of the Samsung rsg5ucrs fridge, you know the filter is on its place. It needs to be twisted a quarter-turn clockwise.
- If the water filter is difficult to remove, there may be water pressure building up behind the filter. Remove the top 2 fridge shelves to be able to pull harder.
- If you still find it hard to install the filter, close the water supply valve of the Samsung rsg5ucrs fridge and dispense a little bit of water. The pressure should be less now, which allows for easier installation of the new filter.
- After installing the new filter, make sure to press the water filter reset button for 3 seconds, to reset the Samsung water filter indicator.

The following instructions are for external filters only (~10% of Samsung rsg5ucrs fridge-freezers carries an internal filter).

- Shut off water supply of the Samsung sg5ucrs
- Disconnect old cartridge from system
- Align the water filter with arrow flow mark toward refrigerator
- Connect the inlet and outlet tubing to the appropriate end of the filter by firmly pushing the tubing all the way until tightly seated
- Make sure the tubing is square and scratch free (trim if necessary)
- Insert filter clip (shown in installation manual)
- Turn on the water and check for leaks
- If leaks occur, repeat installation steps (if leaks persist, discontinue use and call for support)
- Flush the filter of the sg5ucrs for 5 minutes before use, after you have replaced the water filter.

## 2. [DA29-00003F water filter replacement](#)

The DA29-00003F water filter, according to some, is the replacement for the DA29-00003G, DA29-00003B and DA29-00003A. This water filter CAN NOT replace the superior DA29-00003G. This filter is not interchangeable with the DA29-00003G. The filter NSF42

certified to avoid chlorine and sediment. is Replacement of the da29-00003f water filter is completely the same as for many other models.

The following instructions are for internal filters only. Replacement of the da29-00003f water filter:

- To remove the water filter, twist the filter to the left or counterclockwise to unlock
- Gently pull it out and discard (the water will shut off automatically)
- Gently push in the new water filter and turn it to the right
- If the padlock symbol matches up with the symbol on the da29-00003f water filter, you know the filter is on its place. It needs to be twisted a quarter-turn clockwise.
- If the water filter is difficult to remove, there may be water pressure building up behind the filter. Remove the top 2 fridge shelves to be able to pull harder.
- If you still find it hard to install the filter, close the water supply valve of the Samsung fridge and disperse a little bit of water. The pressure should be less now, which allows for easier installation of the new filter.
- After installing the new filter, make sure to press the water filter reset button for 3 seconds, to reset the Samsung water filter indicator.

### 3. How to Light Reset the Samsung fridge water filter

If your Samsung fridge is equipped with a water filter, you will notice that there is a water filter indicator. This indicator is a small light reminds you when it is time to replace the water filter. Normally, it is important to replace the filter every 5-6 months or every 500 oz. of water filtered.

Please be aware that if the filter is old and not clean, the water will not be purified and you are possibly at risk for unwanted contaminations.

These are the colors and their meaning:

- When the filter light is blue, this is how it should always be. Normally the light should always be illuminated. In time it will change colors but it should never be off.
- When the filter light is light pink, it means that the water filter 5 months old.
- If the the filter indicator light is red, it means it is definitely time to change the old water filter and replace it with a new one.
- If the light did not turn on after 6 months, you should still replace your filter.

How to reset the indicator?

Install the new water filter (see above), reset the indicator light by pressing and holding the "Alarm / Hold for 3 seconds to Reset Filter" button. If your model has an inside control panel, hold the "Power Cool" and "Fridge" buttons simultaneously for 3 seconds. This will make sure the light of the Samsung water filter will be reset.

#### 4. [DA29-00003G: Changing a samsung fridge water filter](#)

Important: change the filter at least every 6 months

The following instructions are for internal filters only. The Samsung DA29-00003G water filter is always internally fitted:

- To remove the water filter, twist the filter to the left or counterclockwise to unlock
- Gently pull it out and discard (the water will shut off automatically)
- Gently push in the new water filter and turn it to the right
- If the padlock symbol matches up with the symbol on the filter of the Samsung da-29-00003g water filter, you know the filter is on its place. It needs to be twisted a quarter-turn clockwise.
- If the water filter is difficult to remove, there may be water pressure building up behind the filter. Remove the top 2 fridge shelves to be able to pull harder.
- If you still find it hard to install the filter, close the water supply valve of the Samsung rsg5ucrs fridge and disperse a little bit of water. The pressure should be less now, which allows for easier installation of the new filter.
- After installing the new filter, make sure to press the water filter reset button for 3 seconds, to reset the Samsung water filter indicator.

#### 5. Dangers of not changing your fridge filter every 6 months

A common misconception is that if the indicator light does not turn on after 6 months, the filter should not be changed. This can be hazardous to your health. Contaminants are trapped for 6 months and the water that passes through can even come out dirtier than without filter. Make sure you always have clean water and change your filter in time.

Refrigerator water filters use an activated carbon filter media that is certified for use with a limited quantity of water before you need to change the cartridge out. Activated carbon filters out contaminants from water using adsorption. As the water passes through the filter impurities are captured by the filter media and adhere to the surface of the carbon. Once there is no more surface area available to adsorb new contaminants the filter's capacity has been reached.

At this point most contaminants in the water will simply flow past the filter, unless the filter has become clogged by larger particles. However, if a contaminant passing through the filter has a higher bond with the activated carbon than one that has already been adsorbed, the newer particle will "push" the weaker one out and take its place on the media. So the water leaving the filter could have different contaminants in it than the water that originally entered the filter.